FLOAT-TYPE AIR VENT ½"

Item.№7751

THS® THERMOSTYLE


5 ГОДИНИ ГАРАНЦИЯ 5 YEARS WARRANTY

Performance:

- ✓ ***air chamber against dirt';***
- ✓ ***integrated stop vale;***
- ✓ ***leakage protection.***

- ❖ *max. working temperature +120 °C*
- ❖ *max. pressure 10 bar.*





OPTIONS FOR INSTALATION

HORIZONTAL and VERTICAL position.

A float-type air vent consists of a chamber (body) containing a float attached to a discharge valve by a lever assembly. The float-controlled discharge valve vents air through the large orifice at the top. The float action prevents the escape of any fluid, because the float closes the valve tightly when it rises. When the float drops, the lever assembly pulls the valve from its seat, and the unit discharges air. A float-type air vent used in a steam heating is equipped with a check valve, which prevents air return under vacuum.

www.thermostyle.bg

office@thermostyle.bg